

How To Patch A Cover

As you know accidents happen, and unfortunately they can also happen to your Aquamatic cover.

Should you find yourself with a hole or tear in your fabric, here are some easy steps to help you repair the damage.

*****Depending on the age, condition or the size of the hole, a patch may or may not work.*****

Aquamatic Cover Systems does not recommend patching a hole or tear any larger than 8" in.

Anything greater than that may need to be removed and repaired at the factory.

- 1). You will want to remove any standing water on the cover, and open it to the point where the hole rests on top of the tiled bond beam or deck.
- 2). Using a mild soap and rag, clean the area of the hole, and at least a 3" in. perimeter around it.
- 3). Let the area thoroughly dry. You can use a hair dryer if you wish, do not over heat the fabric.
- 4). Cut the patch material so that it extends 2" in. beyond the hole in all directions. Try to use rounded corners to prevent them from curling up.
- 5). Apply a generous amount of vinyl glue to both the cover and the patch. Wait until the glue gets a hazy appearance, then place it over the hole.
- 6). Starting from the center of the patch, apply pressure and press outward towards the edges. Clean up any glue that oozes out. Apply a weight over the area.
- 7). Let the patch / glue dry for a minimum of 1 hr. before using. A 12 hr. cure time is recommended.
- 8). If at all possible repeat the procedure for the underside of the fabric for added protection.

STANDARD COLORS



DESIGNER COLORS



NEW DESIGNER COLORS



Colors depicted on both the pool cover fabric as well as the composite polymer panels are as close as printing allows. Samples available upon request.